



## HOW TO REMOVE OBSTRUCTED PIGS

### 1. Partial obstruction (lost seal)

- A. Increase volume to rear of pig.
- B. Remove pressure and volume to allow the pig to recover.
- C. Run a line size swab to seal off pig.
- D. Reverse flow direction.

### 2. Obstructed Flow:

- A. Increase pressure to the rear of the pig.
- B. Alternately increase and decrease pressure.
- C. Remove pressure and volume to allow the pig to recover.
- D. Reverse flow direction.

